

Exterior Boundaries:

Line, Veig- nated	Bearing	Chs.	Latitudes		Departures	
			N.	S.	E.	W.
W. Bdy.	S. 0° 06' E.	480		480	0.84	
S. Bdy.	East	480			480	
E. Bdy.	North	480	480			
N. Bdy.	S. 89° 54' W.	480.40		0.84		480.40
Convergence						0.88
			480	480.84	480.84	480.98
			Error Lat. 490	Error Dep. 0.14		490.84