

Dependent Resurvey of a Portion of the West Boundary, T. 7 S., R. 44 E.

Chains	
	<p style="text-align: center;">T7S R43E R44E <u>S13 S18</u> <u>S24 S19</u> 1961</p> <p>Bury the original corner stone alongside the iron post.</p> <p>Raise a mound of stone, 3 ft. base, 2½ ft. high, W. of corner.</p> <p>Land, nearly level. Soil, light gravel, sandy loam. Timber, none. Undergrowth, sagebrush and creosote bush.</p> <hr/> <p>Survey of a Portion of the Subdivisional Lines, T. 7 S, R. 44 E.</p> <hr/> <p>From the cor. of secs. 1, 2, 35 and 36, on the S. bdy., of the Tp. N. 0°05'W., bet. secs. 35 and 36.</p> <p>Over nearly level land through scattering undergrowth.</p>
40.00	<p>Point for the ¼ sec. cor. of secs. 35 and 36.</p> <p>Set an iron post, 30 ins. long, 2½ ins. diam., 24 ins. in the ground, with brass cap mkd.</p>
	<p style="text-align: center;">T7S R44E ^¼ <u>S35 S36</u> 1961</p> <p>Raise a mound of stone, 3½ ft. base, 2½ ft. high, W. of corner.</p>
80.00	<p>Point for the cor. of secs. 25, 26, 35 and 36.</p> <p>Set an iron post, 30 ins. long, 2½ ins. diam., 24 ins. in the ground, with brass cap mkd.</p>
	<p style="text-align: center;">T7S R44E <u>S26 S25</u> <u>S35 S36</u> 1961</p> <p>Raise a mound of stone, 3 ft. base, 2 ft. high, W. of corner.</p> <p>Land, nearly level. Soil, light gravel, sandy loam. Timber, none. Undergrowth, sagebrush and creosote bush.</p>
	<p>From the corner of secs. 25, 30, 31 and 36, on the E. bdy. of the Tp. N. 89°55'W., bet. secs. 25 and 36.</p> <p>Over nearly level land, through scattering undergrowth.</p>
40.08	<p>Point for the ¼ sec. cor. of secs. 25 and 36.</p> <p>Set an iron post, 30 ins. long, 2½ ins. diam., 24 ins. in the ground with brass cap mkd.</p>